



**FITTING INSTRUCTIONS FOR FP0046BK FORK PROTECTORS  
BMW K1200GT '06-, K1200R & K1200S**



**Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike**

- Place appropriate protector at either end of front fork spindles.
- Push bar through
- Slide washers onto exposed ends of the bar.
- Attach nyloc nuts (supplied) to each end of the bar.
- Tighten until it locks up. Do not overtighten – the nyloc nuts will hold it tight.