



FITTING INSTRUCTIONS FOR PKS0007 KICKSTAND SHOE
BMW F800GS 2012



Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike.

THE PARTS SHOWN MAY BE REPRESENTATIVE ONLY (FOR CLARITY OF INSTRUCTIONS ONLY)

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*



BASE PLATE

CLAMP PLATE AND BOLTS

TOOLS REQUIRED

- 3mm A/F Allen key.

FITTING INSTRUCTIONS

- Place the clamp plate (pictured above right) over the side stand base and position up the side stand shaft with the counter-sinks upper-most.
- Take the aluminium machined base plate (picture above left) and fit to the base of the side stand from underneath so it is aligned with the clamp plate.



- Use the three counter-sunk bolts to secure in position, ensuring the inside edge of the clamp plate clamps down on the top of the side stand base
- Tighten all bolts evenly and check to ensure the side stand pad clears the chain when in the raised position.
- If fitting to older stands that have been worn the padding strip should be placed in the base plate to ensure a tighter fit.



Instructions de montage PKS0007 Support de béquille
BMW F800GS 2012



LA FAÇON DONT LE KIT EST EMBALLE NE CORRESPOND PAS FORCEMENT A LA FAÇON DE MONTER LES PIECES SUR LA MOTO.

Les pièces présentées peuvent N'ETRE QUE REPRESENTATIVES (afin de faciliter et clarifier les instructions de montage).

NOTEZ QUE SI LES KITS SONT EMBALLES AVEC DES RONDELLES EN CAOUTCHOUC SERVANT A TENIR LES COMPOSANTS, CES RONDELLES DOIVENT ETRE JETEES.



BASE PLATE

ATTACHE PLATE ET BOULONS

Outils requis

- Clé Allen 3mm

Instructions de montage:

- Placer l'attache plate (Photo en haut à droite) autour de la base de la béquille et positionner l'arbre à béquille latérale dessus.



- Prendre la base plate usinée (Photo en haut à gauche) et placez là à la base de la béquille par dessous de manière à ce qu'elle soit alignée avec la plaque de serrage.
- Utiliser les 3 boulons plats pour fixer la position, en vous assurant que le bord intérieur de la plaque serre sur la partie supérieure de la béquille latérale de base.
- Serrer tous les boulons de façon égale et assurez vous que le support de béquille soit espacé de la chaîne lorsqu'elle est dans la position relevée.
- En cas de montage sur des béquilles usées plus âgées, la bande de remplissage doit être placée sur la base plate pour assurer un ajustement serré.