

Remove injector clip
Insert new injector
Refit clip



Push adapter carefully
over O-ring until fully fitted

